Vehicle-Specific Power Tailgate Lift System

Kia Sorento

2022-2025

Part no. ARKSOR22



Points to Note

- For safety and to ensure proper product use, we recommend professional installation. Do not attempt to disassemble or install the system yourself, as this may result in product damage or personal injury.
- Route each wire harness according to the instructions in this manual, securing them to the vehicle's factory harnesses with cable ties. Ensure the wiring is kept clear of fasteners and screw holes to prevent the harnesses from being crushed or pinched by trim panel clips and screws during reassembly.
- Some wire harness terminals (indicated by the red ellipses below) are left disconnected during manufacturing. Please insert these terminals into their corresponding connectors before routing the harnesses to prevent short circuits. Once routed, connect the remaining harness plugs (indicated by the blue ellipses) to the vehicle's factory plugs.



- Before beginning installation, inspect the vehicle's instrument panel display, verify that all buttons, doors, and windows operate correctly, and check for any pre-existing scratches on the interior or exterior. Report any issues to the customer immediately.

Installation Precautions

- Remove any metal accessories or hard objects from your person during installation to prevent damaging the vehicle's paint, seats, or interior. Carefully store all removed trim components in a safe location to avoid scratches.
- The illustrations in this manual are for reference only. While specific vehicle configurations may vary slightly from the pictures, the general installation methods remain the same.

In the Box

1		Strut	Qty 2
2		Tailgate ECU	Qty 1 set
3		Wire harness	Qty 1 set
4		Power latch	Qty 1
5		Tailgate switch	Qty 1

Other Accessories

Screws, brackets

Recommended Tools



Threading tools



Quick release ratchet wrench set



Electric drill and drill bits



Other tools

Notice

This vehicle-specific kit converts the manual tailgate on the vehicle listed in this manual to power operation. Installation requires a good level of technical knowledge. Please read this manual in its entirety before you start.

Use the correct tools during installation to prevent damage to the vehicle or the product. Please note that we cannot be held liable for any issues arising from improper installation.


Before starting the installation, disconnect the negative battery terminal and make sure the ignition is off and the key is removed or kept away from the vehicle.

Installation





1. Remove the driver's side door sill panels and the fuse box trim panel.
2. Remove the rear right door sill panel.
3. Remove the trim panels on the right side of the boot.
4. Remove the tailgate trim panels.
5. Remove the factory gas struts. To do this safely, remove and replace one strut at a time.
6. Replace the left body bracket.




7 Replace the right body bracket.

8 Replace the left tailgate bracket.

9 Replace the right tailgate bracket.

10 Install the electric struts (L for the left side, R for the right side, as indicated by the first letter of the strut code).


11 Drill a hole at the indicated position with a 21mm hole saw.




12 Thread the strut wire harnesses into the tailgate.

13 Seal the holes on both sides securely.

14 Remove the factory latch and install the power latch.



15 Connect the lock signal harness connectors to the power latch and factory latch connectors.



17 Route the power harness as indicated.


16 Connect the lock signal harness connectors to the factory tailgate switch.

18 Feed the power harness through to the tailgate.


19 Insert the power harness terminals into the connector as shown in the diagram.

20 Connect the ground wire to the indicated position on the tailgate.


21 Connect the power harness connector to the CAN signal connector.




21.1 If you choose not to use CAN, connect the orange wire of the power harness to the indicated orange wire.




22 The fuse box is located in the driver's footwell area; the power supply fuse slot is indicated above.



23 Move the fuse from the fuse box to the fuse tap.



24 Plug the fuse tap into the fuse box, ensuring correct orientation.



25 Secure the tailgate ECU at the indicated position.



26 Connect the left and right strut wire harnesses①②, lock signal harness③, and power harness④ to the tailgate ECU in sequence.




27 Press the new tailgate switch once to close the tailgate; this completes system initialisation. Test each function of the electric tailgate.



28 Install the new tailgate switch and reinstall all trim panels.



(Optional) Drill a 21mm hole using the provided hole saw and fit the front switch.



Note: For models with fewer than 10 wires, just insert them according to the corresponding label or color.

Insert the two terminals of the front switch extension wire into the power harness connector as labelled.

System Initialisation

1. Press the newly installed tailgate switch to close the tailgate automatically.
2. Press the exterior tailgate switch to open it; you will hear a long beep.
3. System initialisation is now complete.

Operating Instructions

1. **Opening and Closing the Tailgate:**
   - Press and hold the unlock button on the remote key;
   - Press the unlock button near the driver 3 times;
   - Press the exterior tailgate switch;
   - Press the newly installed tailgate switch;
   - Press the front switch: press and hold for 4 seconds to open, or press briefly to close.
2. **Pausing the Tailgate:**

   While the tailgate is in motion, press any of the control buttons to pause it. Pressing a button again will reverse the tailgate's direction.

Configuring the Tailgate Switch Settings

1 Adjusting Closing Speed (5 Levels)

1. Press and hold the switch button until hearing the first short beep sound.
2. Release the button; a short beep confirms the new closing speed is set.
3. Repeat this process to increase the speed by one level.

2 Adjusting Opening Speed (5 Levels)

1. Press and hold the switch button until hearing the second short beep sound
2. Release the button; two short beeps confirm the new opening speed is set.
3. Repeat this process to increase the speed by one level.

3 Voice Module Configuration

1. Press and hold the switch button until hearing the third short beep sound.
2. Release the button; three short beeps confirm the voice module has entered configuration mode. (For details, see the voice module operation manual.)

4 Muting the Voice Module

1. Press and hold the switch button until hearing the fourth beep sound.
2. After releasing the button, you will hear three four beeps indicating that the voice module has been blocked.

5 Setting the Maximum Opening Height

1. Press and hold the switch button until hearing the fifth short beep sound.
2. Release the button; a long beep confirms the height setting is set.

6 Remote Key Unlock Button Sensitivity (Quick/Slow Press)

1. Press and hold the switch until you hear the sixth short beep.
2. Release the button; a long beep followed by a short beep confirms the switch between quick and slow unlock button presses has taken effect.

7 Remote Key Activation (Double-Press vs. Triple-Press)

1. Press and hold the switch until you hear the seventh short beep.

2. After releasing the button, you will hear a long beep sound and two short beeps indicating that the switch between pressing the unlock button twice/three times has taken effect.

8 Adjusting Braking Force (5 Levels)

1. Press and hold the switch until you hear the eighth short beep.
2. Release the button; a long beep followed by three short beeps confirms the switch between pressing the unlock button twice or three times has taken effect.
3. Repeat this process to increase the setting by one level.

9 Factory Reset

1. Press and hold the switch until you hear the ninth short beep.
2. Release the button; a long beep followed by four short beeps confirms the factory settings have been restored.

Buzzer Sound Indicators

One Beep: The tailgate immediately opens, closes, or pauses upon receiving the corresponding signal.

Two Beeps: The tailgate is fully opened or fully closed.

Three Beeps: The tailgate encountered excess resistance; the intelligent anti-pinch safety feature has been activated.

Technical Support

If you need help setting up or using your Aerpro product, now or in the future, call Aerpro Support Australia on 03 8587 8889, Monday to Friday, 9am to 5pm AEST.

To download a digital copy of this manual, or other Aerpro manuals and software, visit aerpro.com.