V1. 03/18



... connecting to the aftermarket

CT23VL03

Volvo Double Din Fascia Plate



Vehicle Application

Volvo XC90 2006-2014

Key Features

- This fascia kit allows the installation of an aftermarket head unit into a non din sized aperture
 - High quality finish designed to match the vehicle dashboard
 - Fascia kit supplied with cage and fitting accessories





The information provided in this document is subject to change without notice due to changes and/or improvements to the product/s.

ABOUT THIS PRODUCT

CT23VL03

Volvo Double Din Fascia Plate (Black)

INSTALLATION KIT INCLUDES

1x 2-ISO 110mm Metal Bracket 1x Radio Trim 1x Replacement Panel 2x Mounting Plates 2x Mounting Spacers 2x Radio Removal Keys 4x Screws

PRIOR TO INSTALLATION

Read the manual prior to installation. Technical knowledge is necessary for installation. The place of installation must be free of moisture and away from heat sources. Please ensure that the correct tools are using during the installation to avoid damage to the vehicle or product. **Connects2 can not be held responsible for the installation of this product.**

TECHNICAL SUPPORT

Connects2 Ltd. want to provide a fast and suitable resolution to any problems encountered during installation of this product. To get in touch with our dedicated technical support team, please fill in a ticket at **support.connects2.com** and provide as much information as possible.



FITTING GUIDE

1. Use a panel removal tool to unclip the trim panel from around the gear stick, and remove the panel

2. Remove the two (2) Torx screws as highlighted by the arrows in the image

3. Remove the OEM fascia panel and climate control unit from the dashboard

4. Remove the radio panel from the climate control unit

5. Remove the plastic at the backside of the panel as highlighted in the image




3











FITTING GUIDE

6. Reinstall the climate control unit into the dashboard and fit the new fascia panel

7. Push the metal cage into the opening in the fascia panel.

8. Use a screwdriver to attach the brackets to the right and left sides of the aftermarket stereo as shown in the images (right, below)

NB: We advise to use the following positions. Use Position 1 marked with a cross. Use Position 10 & 12 marked with an arrow.

Use this hole Use this hole

9. Reconnect all wiring to the aftermarket stereo and test for correct operation.

Push the aftermarket stereo into the dashboard until it clips into place, and surround the stereo with the trim panel to complete the installation













